

ENLARGING YOUR NEGATIVES

1. PLACE NEGATIVE STRIP, **SHINY SIDE UP** INTO ENLARGER NEG CARRIER ROTATE NEGATIVE 180 DEGREES SO IT WON'T APPEAR UPSIDE DOWN PLACE EASEL ON ENLARGER BASE
2. SET TIMER TO **FOCUS** (TURNING LIGHT ON IN ENLARGER)
3. OPEN LARGER LENS TO PROJECT A BRIGHT IMAGE ON EASEL
4. RAISE ENLARGER HEAD TO FILL EASEL WITH IMAGE WITH A GOOD COMPOSITION
5. FOCUS IMAGE BY EYE, THEN USE **FINE GRAIN MAGNIFIER**
6. Stop down Enlarger lens 2 or 3 stops. (Makes light dimmer)
7. SET TIMER TO 5 SEC DURATION
8. SET TIMER TO TIMER MODE
9. PLACE TEST STRIP ON EASEL SHINY SIDE UP!
10. COVER TEST STRIP EXCEPT FOR A 1 CM STRIP WHILE EXPOSING FOR 5 SEC WITH LIGHT
11. REVEAL MORE PHOTO PAPER AND REPEAT FOR TWO OR THREE MORE 5 SEC INTERVALS
12. DEVELOP TEST STRIP
13. DECIDE ON CORRECT TIME FOR EXPOSURE. SET ON ENLARGER TIMER!!
14. PLACE PAPER IN EASEL AND EXPOSE FOR CORRECT INTERVAL
15. DEVELOP PRINT
16. PLACE IN RACK TO DRY, OR HANG UP IN DRYING CABINET

DON'T FORGET YOUR NEGATIVES IN ENLARGERS